

Analogic Gas Detector



Part Number: NP300GB

Revision: K.2

→06/2015

Copyright © 2015 by *Oldham S.A.S.*

Juli 2015

All rights reserved. No reproduction of all or part of this document, in any form, is permitted without the written consent of *Oldham S.A.S.*

All information provided in this document is accurate to the best of our knowledge.

As a result of continuous research and development, the specifications of this product may be changed without prior notice.

Oldham S.A.S

Rue Orfila

Z.I. Est – CS 20417

F – 62027 ARRAS Cedex

Tel : +33 (0)3 21 60 80 80

Fax: +33 (0)3 21 60 80 00

Contents

Chapter 1 | General Information5
User Manual5
Symbols used.....5
Safety instructions6
Important information6
Liability limits7

Chapter 2 | Introduction9
General Information9
CTX300 CO₂ versions10
Composition11

Chapter 3 | Installation and connection13
Installing the detectors13
Electrical connections15

Chapter 4 | Powering up and use21
Powering up21
4-20 mA analog output22

Chapter 5 | Maintenance23
Calibration23
Replacing a sensor37
Disposal.....37

Chapter 6 | Spare parts39
CTX/COX 300 toxic or oxygen sensors39
CSC 300 semiconductor sensors.....42
CTX 300 – CO₂ sensors43

Chapter 7 | Certification45

Chapter 8 Technical specifications49

Chapter 9 | Annex53

Indications for calibrating the *CTX 300 SC*53

CTX 300 overview54

Chapter 1 | General Information




User Manual

The instructions given in this manual must be read thoroughly before installation and start-up, particularly those concerning the points related to the safety of the end-user. This user manual must be made available to every person involved in the activation, use, maintenance, and repair of the unit. The information, technical data, and diagrams contained in this manual are based on the information that is available at a given time. In case of doubt, contact *Oldham* for additional information.

The aim of this manual is to supply simple and accurate information to the user. *Oldham* cannot be held liable for any misinterpretations in the reading of this manual. In spite of our efforts to produce an error-free manual, it may nonetheless contain some unintentional technical inaccuracies.

In the client's interest, *Oldham* reserves the right to modify the technical characteristics of its equipment to increase their performance without prior notice. The present instructions and their content are the inalienable property of *Oldham*.

Symbols used

| Icon | Significance |
|---|---|
|  | This symbol indicates useful additional information. |
|  | This symbol indicates: This equipment must be connected to ground. |
|  | This symbol indicates: Protective earth terminal. A cable of the adequate diameter must be connected to ground and to the terminal having this symbol. |



This symbol indicates:
You must refer to the instructions.



This symbol indicates:
Warning! In the present mode of use, failure to adhere to the instructions preceded by this symbol can result in a risk of electric shock and/or death.



European Union (and EEA) only. This symbol indicates that this product must not be discarded with household waste, as per the EEA directive (2002/96/EC) and your own national regulations.

This product must be disposed of at a collection point that is reserved for this purpose, for example, an official site for the collection of electrical and electronic equipment (EEE) in view of their recycling, or a point of exchange for authorized products that is accessible when you acquire a new product of the same type.

Any deviation as regards these recommendations for the disposal of this type of waste can have negative effects on the environment and public health, as these electric and electronic products generally contain substances that can be dangerous. Your full cooperation in the proper disposal of this product promotes a better use of natural resources.

Safety instructions

Labels intended to remind you of the principal precautions of use have been placed on the unit in the form of pictograms. These labels are considered an integral part of the unit. If a label falls off or becomes illegible, please ensure it is replaced. The significance of the labels is detailed below.



The installation and electrical connections must be carried out by qualified personnel according to the instructions of the manufacturer and the standards of the competent authorities.

Failure to adhere to the instructions can have serious consequences on the safety of persons. Please be extremely rigorous as regards electricity and assembly (coupling, network connections).

Important information

The modification of the material and the use of parts of an unspecified origin shall entail the cancellation of any form of warranty.

The use of the unit has been projected for the applications specified in the technical characteristics. Exceeding the indicated values cannot in any case be authorized.

Liability limits

Neither *Oldham* nor any other associated company under any circumstances can be held liable for any damage, including, without limitations, damages for loss or interruption of manufacture, loss of information, defect of the *MX 43* control unit, injuries, loss of time, financial or material loss, or any direct or indirect consequence of loss occurring in the context of the use or impossibility of use of the product, even in the event that *Oldham* has been informed of such damage.

Chapter 2 | Introduction

General Information

CTX300 gas detectors are designed to measure toxic gases or vapors and oxygen. With robust materials, a specifically-adapted design, appropriate accessories, stainless bolts and a polyamide case (IP54), CTX 300 detectors are designed to withstand the roughest conditions.



Figure 1: overview of a CTX 300 with display (left) and without display (right).

CTX300 CO₂ versions



In the case of a CTX 300 for the CO₂ detection, this manual can only be used for devices delivered before July 2015.



P/N : 6514879

P/N : 6514880

P/N : 6514881

P/N : 6514882

Figure 2: CTX 300 CO₂ detector delivered before July 2015



P/N : 6314124

Figure 3: CTX 300 CO₂ detector delivered since July 2015

Composition

| Sensor type | CTX 300 | | | |
|---------------------|---|---|---|--|
| | Toxic | Oxygen | Semi-conductor | CO ₂ ¹ |
| Gases detected | Common toxic gases detected. | Oxygen. | - Combustible gas. - Solvents. - Some Freons. | CO ₂ . |
| Detection method | Electrochemical sensors (1). | Electrochemical sensor. | Semiconductor sensor. | Infrared absorption. |
| Type of sensor pack | Pre-calibrated removable sensor pack (2). | Pre-calibrated removable sensor pack: 0-30% scale or 0-100% volume. | Removable sensor pack, not pre-calibrated. | Removable sensor pack Infrared column, not pre-calibrated. |
| Options | With display. | With display. | | |
| Certification | None. | None | None | None |

(1) Specific to each gas.

(2) Choice between several scales.

¹ CTX 300 CO₂ detector delivered before July 2015

Chapter 3 | Installation and connection

Installing the detectors

Layout

While the measuring sensor is always located on the underside of the detector, several factors determine where the detector should be located:

- If the gas being measured is lighter than the air, place the detector near the ceiling.
- If the gas is heavier than the air (CO₂ and Freons, for example) place the detector close to the floor.
- Near offtake points.
- Generally, in locations where gas may accumulate, taking into consideration both:
 - The effects of temperature;
 - The outside winds direction.

Determining the best sensor location

Factors to consider when determining the best placement for the detector are:

- Potential sources for vapor and gas emissions.
- Characteristics of gases and vapors (density).
- Air circulation:
 - Inside: mechanical or natural ventilation.
 - Outside: wind direction and velocity.
- Effects of temperature.
- Local constraints (air flow, water splash, etc.).

Detectors should always be located in an easily accessible location for maintenance purposes.

Special accessories may be necessary to protect the equipment against any liquid projectiles, dust, direct sunlight or low temperatures in the area.

Mechanical installation




Figure 4: overall dimensions of the CTX 300.




Figure 5: drilling diagram for wall mounting (view of the side flatten onto the ceiling).




Figure 6: ceiling mounting with a brace. The fixing drawing is identical to this of the wall mount.

| Ref. | Qty | Description | Code | Material |
|------|-----|-----------------|---------|-----------|
| 1 | 1 | Brace | 6132380 | Stainless |
| 2 | 4 | Washer A25 ACCD | 6905518 | Stainless |
| 3 | 4 | Screw CHC LI2 | 6902218 | Stainless |

Electrical connections

Wiring specifications

If needed, consult the grounding instructions for *Oldham* instruments and related connection materials in Annex 1.

Connections for the various types of sensors

| Wire | CTX 300 (TOX/OX) with display | CTX 300 (TOX/OX) without display | CTX 300 SC/CO ₂ without display |
|---------------|----------------------------------|-------------------------------------|---|
| Output signal | 4-20 mA | 4-20 mA | 4-20 mA |
| Active wires | 3 | 2 | 3 |
| Cable entry | 1 x 6-11 mm | 1 x 6-11 mm | 1 x 6-11 mm |

Connection of a 3-wire sensor to an Oldham control unit

| Wire | Terminal number |
|------------------------------------|-----------------|
| (+) V DC power supply: | 3 |
| (-) V DC power supply (masse 0 V): | 2 |
| Output signal: | 1 |




Figure 7: connection of a 3-wire sensor to an Oldham control unit.

Connection of a 2-wire sensor to an Oldham control unit

| Wire | Terminal number |
|------------------------|-----------------|
| (+) V DC power supply: | 3 |
| Output signal: | 1 |

Both wires are the 4-20 mA 2-wire loop.




Figure 8: connection of a 2-wire sensor to an Oldham control unit.

Connection of a 3-wire CTX300 sensor to a non-OLDHAM control unit with an internal power supply




Figure 9: Connection of a 3-wire CTX300 sensor to a non-OLDHAM control unit.

- (R) Maximal load = 200 Ω .
- (A) Power supply $15 \leq V_{cc} \leq 32$.
 $18 \leq V_{cc} \leq 30$ for CO₂ sensor.
 $I_{max} = 130$ mA.

Connection of a 2-wire 4-20mA sensor to a non-Oldham control unit and to an internal power supply




Figure 10: Connection of a 2-wire 4-20mA sensor to a non-Oldham control unit.

- (A) Power supply $15 < V_{CC} < 32V$. $I_{max} = 30$ mA.

Operating mode

CTX300 with display

- Remove the 4 screws (ref. 1).
- Remove the cover (ref. 2).



Figure 11

- Completely remove the screw (ref. 4).
- Unscrew the screw a few turns (ref. 3).



Figure 12

- Turn the display circuit as shown (ref. 5).
- Connect the cable (ref. 6) to the connector. Refer to paragraph *Connections for the various types of sensors* on page 15.
- Return the display circuit to its original position and replace the cover.




Figure 13

CTX 300 without display

- Unscrew the 4 screws (ref. 1).
- Remove the cover (rep. 2).
- Proceed to wire the sensor according to the terminal location.



Figure 14

Chapter 4 | Powering up and use

Powering up

- The sensor turns on when connected to a power supply.
- If the sensor has a display, the green LED will be lit (ref. 2) and a value will appear on the display screen (ref. 1).



Figure 15

In case of a problem, verify that the maintenance switch (ref. 1), located on the main circuit, is in the *MES* (measure) position.



Figure 16: CTX 300 circuit board.




Figure 17: CTX 300 SC main circuit board.



Figure 18: CTX 300 CO₂ main circuit board. This card does is not equipped with a *MES-CAL* switch.

4-20 mA analog output

For *CTX 300* sensors, except for the CO₂ sensor, the 4-20 mA output current is proportional to the gas level.

Notes:

- The CO₂ sensor can be equipped with a linearization board.
- *MX 15* and *MX 32* control units that integrate with the linearization of the CO₂ sensor are available upon request.
- The *MX 62* integrates with the linearization of CO₂ sensors.

The various states of the 4-20 mA output are:

- ≤ 1 mA to indicate a fault.
- = 2 mA in *Calibration* position, except for the CO₂ sensor that does not have a calibration function.
- Between 4 and 20 mA for measurement values.
- ≥ 20 mA if levels exceed measurement range.

Chapter 5 | Maintenance



The adjustment operations in this paragraph are reserved for authorized, trained personnel because they may compromise detection reliability.

Gas detectors are safety devices. OLDHAM recommends the regular testing of fixed gas detection installations. This type of test consists of injecting the calibration gas into the detector at a sufficient concentration to activate the pre-set alarms. It is to be understood that this test is in no way a replacement for a detector calibration.

The frequency of gas tests depends on the industrial application where the detector is in use. Frequent inspections should be made in the months following the commissioning of the installation, and should then become more widely spaced provided that no significant deviation is observed. If a detector should fail to react in contact with the gas, calibration is essential. The frequency of calibrations shall be appropriate according to the results of the tests (humidity, temperature, dust, etc.); however, it must not exceed one year.

The general manager should put safety procedures in place on-site. OLDHAM cannot be held responsible for their enforcement.

Calibration Recommendations

Calibration consists of adjusting the zero of the clean air sensor and adjusting sensitivity with a test gas. Adjustments are made at the sensor level.

Equipment needed to calibrate the detector correctly:

- Flexible plastic tubing (Figure 19, ref. 2).
- Manometer and regulator valve for the compressed gas cylinders (ref. 3).
- 0 to 60 l/h flow meter (if the cylinder is not equipped with one).
- Calibration pipe (ref. 1), which may vary depending on the nature of the gas (see pages 39 and following).
- Test gas cylinder (ref. 4).



Figure 19: sensor calibration assembly.

Zero adjustment should be performed in a gas and vapor free area. If this is not possible, synthetic bottled air can be injected at a rate of 60 l/h.

Use a bottle of test gas to adjust sensor sensitivity (concentration close to the alarm threshold or corresponding to 30% of the measurement range at a minimum). The recommended rate is 60 l/h.

Note: when dealing with dangerous gases, you **MUST** consult a specialized *Oldham* technician or use another sensor pack recently pre-calibrated at a factory.



The detector should be calibrated using the intended flow-rate. The actual concentration of gas may be underestimated if the detector was calibrated with too high of a flow rate.

CTX 300 calibration

1st case: CTX 300 with display (excluding O₂)

- The sensor is operating: the green light (ref. 1) is lit and the display screen shows the measurement level.




Figure 20

- Flip the maintenance switch (ref. 1) into the **CAL** (calibration) position: the yellow light (Figure 20, ref. 2) will be lit and the sensor will send a 2 mA current to the control unit (*Maintenance mode*).
- Verify that the sensor is located in a clean-air environment. If not, inject synthetic air at a flow rate of 30 l/h.




Figure 21

- Wait for the measurement to stabilize (displayed on screen) and adjust the zero by using the **ZERO** potentiometer located on the sensor pack (ref. 2).
- Inject the recommended calibration gas at a flow rate of 30 l/h.
- Wait for the measurement to stabilize.
- Adjust the sensitivity by using the sensitivity potentiometer located on the sensor pack (rep. 1).
- Stop injecting the calibration gas.
- Remove the gas injection pipe, then wait and verify that the signal returns to zero. Repeat procedure if it does not.



Figure 22

- Flip the maintenance switch (rep. 1) into the **MES** (measure) position. The yellow light will turn off (Figure 20, rep. 2).
- Calibration is complete.




Figure 23

2nd case: CTX 300 without display (except for O₂, SC and CO₂)

- The sensor is operating.
- Flip the maintenance switch (ref. 1) into the **CAL** (calibration) position: the sensor will send a 2 mA current to the control unit (*Maintenance mode*).
- Verify that the sensor is located in a clean-air environment. Use the calibration kit and follow all recommendations.




Figure 24

- Connect a voltmeter to the AF+ and AF- terminals (caliber mV/DC).




Figure 25

- Wait for the signal to stabilize and adjust the *zero* by using the ZERO potentiometer located on the sensor pack (Figure 26, ref. 2). The output signal should be 0 mV.
- Now inject the recommended test gas at a flow rate of 30 l/h. Use the calibration kit and follow all recommendations.
- Wait until the signal has stabilized.
- Read the mV value on the voltmeter (Figure 25), with the full scale at 1600 mV. Calculate the value to be read as a function of your test gas.



Figure 26

- Adjust the displayed value using the potentiometer (Figure 26, rep.1).

Example

- *CO sensor.*
- *Scale 0-300 ppm.*
- *Standard gas concentration: 100 ppm.*
- *Reading: 533 mV.*
- Shut off the calibration gas injection.
- Withdraw the gas injection pipe.
- Then wait and check that the scale has returned to zero. Otherwise, repeat the entire procedure.
- Switch the maintenance on/off switch to the *MES* (measure) position (ref. 1).




Figure 27

CTX 300 calibration for O₂

This sensor is an Oxygen type.

1st case: CTX 300 O₂ with display

- See paragraph 1st case: CTX 300 with display, on page 24. Proceed only with adjusting sensitivity (rep. 1) by injection of test gas.



Figure 28

2nd case: CTX 300 O₂ without display screen nor LED

- See paragraph 2nd case: CTX 300 without display on page 26. Proceed only with adjusting sensitivity (rep. 1) by injection of test gas.

Signal value mV:

- 1600 mV for full scale, means 30 % O₂.
- 1115 mV for 20.9 % O₂.
- 0 mV for 0% O₂.



Figure 29

Note: the signal sent from the CTX300 (toxic or oxygen) sensor to the control unit can be measured on the main circuit by connecting a millivoltmeter to the pins designed for this purpose (Figure 30).

- 400 mV corresponds to 4 mA.
- 2000 mV corresponds to 20 mA.



Figure 30

CTX 300 calibration (for Semiconductor)

This is a *Semiconductor* type sensor.

- Flip the switch (rep. 1) into the **CAL** position.



Figure 31

- Ensure that the sensor is in clean air, otherwise inject synthetic air into it using the calibration kit and referring to the recommendations below.

Important: to correctly calibrate a sensor equipped with a semiconductor cell, use of a humidifier kit (code 6335919) is MANDATORY.

Using the humidifier kit

- Lift the lid (ref. A) and, using a washbottle, moisten the filter, without saturating it, with distilled water
- Replace the lid and check that all parts are properly assembled and that the assembly is fully airtight.
- Adjust the flow rate to 60 l/h and wait 10 minutes until the humidifier is fully purged.
- Apply the gas introduction pipe (ref. C) to the nose of the sensor and wait at least five minutes for the measurement to stabilize.

Note: the sensor must be powered for at least two hours before any adjustment can be made.




Figure 32: the humidifier kit.

- Connect a voltmeter as indicated and adjust, using potentiometer p5 (ref. 1). The output signal must be equal to 880 mV.
- Next, inject the calibration gas at a flow rate of 30 l/h (refer to paragraph *Indications for calibrating the CTX 300 SC*, on page 53).
- Wait for the signal to stabilize and adjust the signal with the sensitivity potentiometer p6 (ref. 2).

The output signal should be:




Figure 33

$$U = 880 \text{ mV} + \frac{3520 \text{ mV} \times \text{Cal gas concentration}}{\text{Sensor measurement range}}$$

Example

| Sensor measure (% of full range) | Output signal (mV) |
|-------------------------------------|-----------------------|
| 0 | 880 |
| 50 | 2 640 |
| 100 | 4 400 |

- Stop injecting the calibration gas.
- Verify that the reading returns to zero (880 mV). If it does not, repeat the entire procedure.
- Calibration is complete.
- Flip the switch (ref. 1) into the MES (Measure) position.




Figure 34

CTX 300 CO₂ calibration¹

This is a *Carbone dioxide* type sensor.



- Warning: the sensor should be turned on for 15 minutes before adjustments are made. The following text describes the steps necessary to adjust the transmitter (first calibration).
- Adjustment: if the current loop of the output signal has an impedance of 500 ohms, the power supply should never fall below 23 V DC.

- Inject nitrogen at a rate of 30 l/h.
- On the X1 terminal board, place an ammeter between terminals 1 (+) and 2 (-).
- With the potentiometer Z, adjust the current to 4 mA.
- With the ammeter still connected, inject the test gas at a rate of 60 l/h.
- Adjust the sensitivity with the potentiometer S. Refer to the paragraph *Calibration curves*, on page 32 for sensors without linearization cards.
- If this fails, flip the J2 jumper and begin again.




Figure 35

¹ CTX 300 CO₂ detector delivered before July 2015

CTX 300 CO₂ linearization card

- If you use a linearization card, the connection is the following.

| Terminal A | Central terminal number |
|------------|-------------------------|
| 2 (GND) | 1 |
| 3 (+24V) | 3 |
| 1 (I out) | 2 |

| Terminal B | Central terminal number |
|------------|-------------------------|
| In | Iout |
| GND | GND |
| +24V | +24V |





Figure 36

Calibration curves

The following pages present the calibration curves, that means the output signal of different CO₂-IR transmitters.


- CO₂ sensor, 0-1 % scale.
- CO₂ sensor, 0-5 % scale.
- CO₂ sensor, 0-10 % scale.
- CO₂ sensor, 0-50 % scale.



| ppm CO ₂ | Display % range | Current mA |
|---------------------|-----------------|------------|
| 0 | 0 | 4 |
| 500 | 14 | 6.24 |
| 1000 | 27 | 8.32 |
| 1500 | 35 | 9.6 |
| 2000 | 43 | 10.88 |
| 2500 | 49 | 11.84 |
| 3000 | 55 | 12.8 |
| 3500 | 60 | 13.6 |
| 4000 | 64 | 14.24 |
| 4500 | 68 | 14.88 |
| 5000 | 71 | 15.36 |


| ppm CO ₂ | Display % range | Current mA |
|---------------------|-----------------|------------|
| 5500 | 76 | 16.16 |
| 6000 | 79 | 16.64 |
| 6500 | 82 | 17.12 |
| 7000 | 85 | 17.6 |
| 7500 | 88 | 18.08 |
| 8000 | 90 | 18.4 |
| 8500 | 93 | 18.88 |
| 9000 | 96 | 19.36 |
| 9500 | 98 | 19.68 |
| 10000 | 100 | 20 |

Figure 37: signal CO₂-IR transmitter output signal – 0-1 % scale.




| % CO ₂ | Display % range | Current mA |
|-------------------|-----------------|------------|
| 0,00 | 0 | 4,0 |
| 0,25 | 21.6 | 7.46 |
| 0,50 | 33.1 | 9.3 |
| 1,00 | 48.4 | 11.74 |
| 1,50 | 60.1 | 13.62 |
| 2,00 | 68.6 | 14.98 |
| 2,50 | 75.6 | 16.1 |
| 3,00 | 82.4 | 17.18 |
| 3,50 | 86.7 | 17.87 |
| 4,00 | 91.7 | 18.67 |
| 4,50 | 95.8 | 19.33 |
| 5,00 | 100 | 20 |

Figure 38: signal CO₂-IR transmitter output signal – 0-5 % scale.



| % CO ₂ | Display % range | Current mA |
|-------------------|--------------------|---------------|
| 0,00 | 0 | 4,0 |
| 1,00 | 41.25 | 10,6 |
| 2,00 | 56.875 | 13,1 |
| 3,00 | 67.5 | 14,8 |
| 4,00 | 75.625 | 16,1 |
| 5,00 | 80.625 | 16,9 |
| 6,00 | 86.875 | 17,9 |
| 7,00 | 91.25 | 18,6 |
| 8,00 | 95.625 | 19,3 |
| 9,00 | 98.75 | 19,8 |
| 10,00 | 100 | 20,0 |

Figure 39 : signal CO₂-IR transmitter output signal – 0-10 % scale.



| % CO ₂ | Display % range | Current mA |
|-------------------|-----------------|------------|
| 0 | 0 | 4,0 |
| 1 | 13.4 | 6.14 |
| 2 | 21.6 | 7.46 |
| 3 | 28.4 | 8.54 |
| 5 | 38.1 | 10.1 |
| 10 | 54.6 | 12.74 |
| 15 | 66 | 14.87 |

| % CO ₂ | Display % range | Current mA |
|-------------------|-----------------|------------|
| 20 | 74.2 | 15.87 |
| 25 | 80.4 | 16.86 |
| 30 | 85.6 | 17.7 |
| 35 | 90.7 | 18.51 |
| 40 | 93.8 | 19.01 |
| 45 | 96.9 | 19.5 |
| 50 | 100 | 20 |

Figure 40 : signal CO₂-IR transmitter output signal – 0-50 % scale.

Replacing a sensor

Sensors must be replaced:

- When calibration is no longer possible (no sensitivity);
- During preventative maintenance.

The replacement sensor should be identical to the original sensor (same gas, same range). After a sensor has been replaced, a calibration or test (for pre-calibrated sensors) must be conducted.

Disposal



For the preservation, protection and improvement of environmental quality, and for the protection of human health and the prudent and rational utilization of natural resources, the *CTX 300* must be disposed of separately from electronic equipment and cannot be disposed of with normal household waste. The user therefore has an obligation to separate the *CTX 300* sensor from other waste to ensure that it is recycled safely for the environment. For further details on existing collection sites, contact the local administration or seller of the product.





Chapter 6 | Spare parts

List of spare parts for different detectors.



Replacement parts must imperatively be guaranteed origin *Oldham*. Otherwise, material safety could be jeopardized.






CTX/COX 300 toxic or oxygen sensors

| P/N | Description | Picture |
|---------|---|---|
| 6147868 | CTX 300 tool kit. |  |
| 6322420 | Mounting brace and bolts (CTX 300) ceiling mount. |  |
| 6323607 | Gas collector (s). |  |
| 6331137 | Gas introduction device for O ₂ , CO, H ₂ S, NO, H ₂ . |  |
| 6331141 | Gas introduction device for explosible gases and other toxic gases. | |



| P/N | Description | Picture |
|---|--|---|
| 6327906 | Device for remote gas introduction. |  |
| 6335953 | Replacement filter. PTFE protector filter. |  |
| <i>Pre-calibrated oxygen sensor pack</i> | |  |
| 6313C2A | CTX 300 O ₂ , 0-30 % vol sensor pack. (2years) | |
| 6313C5A | CTX 300 O ₂ , 0-30 % vol sensor pack. (5years) | |
| 6313660 | CTX 300 O ₂ , 0-100 % vol sensor pack. | |
| <i>Pre-calibrated toxic sensor pack</i> | |  |
| 6313627 | CTX 300 CO - 100 ppm sensor pack. | |
| 6313628 | CTX 300 CO - 300 ppm sensor pack. | |
| 6313629 | CTX 300 CO - 1000 ppm sensor pack. | |
| 6313631 | CTX 300 CO - 1% vol sensor pack. | |
| 6313632 | CTX 300 CO - 10% vol sensor pack. | |
| 6313633 | CTX 300 H ₂ S - 30 ppm sensor pack. | |
| 6313634 | CTX 300 H ₂ S - 100 ppm sensor pack. | |
| 6313635 | CTX 300 H ₂ S - 1000 ppm sensor pack. | |
| 6313636 | CTX 300 NO - 100 ppm sensor pack. | |
| 6313637 | CTX 300 NO - 300 ppm sensor pack. | |
| 6313638 | CTX 300 NO - 1000 ppm sensor pack. | |
| 6313639 | CTX 300 NO ₂ - 10 ppm sensor pack. | |
| 6313640 | CTX 300 NO ₂ - 30 ppm sensor pack. | |
| 6314001 | CTX 300 NO ₂ - 100 ppm sensor pack. | |
| 6313645 | CTX 300 ETO - 30 ppm sensor pack. | |
| 6313646 | CTX 300 SO ₂ - 10 ppm sensor pack. | |
| 6313647 | CTX 300 SO ₂ - 30 ppm sensor pack. | |
| 6313648 | CTX 300 SO ₂ - 100 ppm sensor pack. | |

| P/N | Description | Picture |
|---------------------------------|---|---------|
| 6313649 | CTX 300 Cl ₂ - 10 ppm sensor pack. | |
| 6313650 | CTX 300 H ₂ - 30 ppm sensor pack. | |
| 6313651 | CTX 300 H ₂ - 100 ppm sensor pack. | |
| 6313652 | CTX 300 HCL - 30 ppm sensor pack. | |
| 6313653 | CTX 300 HCL - 100 ppm sensor pack. | |
| 6313654 | CTX 300 HCN - 10 ppm sensor pack. | |
| 6313655 | CTX 300 HCN - 30 ppm sensor pack. | |
| 6313656 | CTX 300 NH ₃ - 100 ppm sensor pack. | |
| 6313657 | CTX 300 NH ₃ - 1000 ppm sensor pack. | |
| 6313893 | CTX 300 NH ₃ - 0-5000 ppm sensor pack. | |
| 6313675 | CTX 300 HF - 10 ppm sensor pack. | |
| 6313676 | CTX 300 O ₃ - 1 ppm sensor pack. | |
| 6313677 | CTX 300 PH ₃ - 1 ppm sensor pack. | |
| 6313919 | CTX 300 PH ₃ - 1000 ppm sensor pack. | |
| 6313860 | CTX 300 F ₂ - 1 ppm sensor pack. | |
| 6314183 | CTX 300 CH ₂ O - 50 ppm sensor pack. | |
| 6 314 185 | CTX 300 ASH ₃ - 1 ppm sensor pack. | |
| 6313834 | CTX 300 SIH ₄ - 50 ppm sensor pack. | |
| 6313678 | CTX 300 ClO ₂ - 3 ppm sensor pack. | |
| 6313833 | CTX 300 COCl ₂ - 3 ppm sensor pack. | |
| <i>Replacement parts</i> | | |
| 6323608 | Cover without display. | |
| 6323609 | Cover with display. | |
| 6815919 | CTX 300 without display label. | |
| 6815921 | CTX 300 wit display label. | |
| 6451466 | Display card. | |
| 6815923 | <i>Localization</i> sticker. | |
| 6451465 | Motherboard. | |

CSC 300 semiconductor sensors

| P/N | Description | Picture |
|-----------------------------------|---|---|
| 6147868 | CTX 300 tool kit. |  |
| 6322420 | Mounting brace and bolts (CTX 300 ceiling mount). |  |
| 6323607 | Gas collector (stainless). |  |
| 6335919 | Calibration kit (humidifier filter + pipe). | |
| 6335918 | Humidifier filter. |  |
| <i>Replacement sensors</i> | | |
| 6313544 | Sensor for R134A, R11, R23, R143A, R404A, R507, R410A, R32, R407C, R408A. |  |
| 6313545 | Sensor for methyl chloride, methylene chloride. | |
| 6313546 | Sensor for solvents. | |
| 6313547 | Sensor for R22, R12. | |
| 6313464 | Sensor for VOC. | |
| <i>Replacement parts</i> | | |
| 6451396 | Motherboard. | |
| 6143502 | PG9 cable gland. | |

CTX 300 – CO₂ sensors¹

| P/N | Description | Picture |
|-----------------------------------|---|---|
| 6147868 | CTX 300 tool kit. |  |
| 6451618 | Motherboard. | |
| 6351233 | Linearization card. | |
| 6799188 | Gas introduction device. |  |
| <i>Replacement sensors</i> | | |
| 6451612 | CO ₂ - 0 - 1 % sensor. | |
| 6451611 | CO ₂ - 0-5 % or 0-10 % sensor. | |
| 6451610 | CO ₂ - 0 - 50 % sensor. | |
| <i>Replacement parts</i> | | |
| 6815923 | <i>Localization</i> sticker. | |
| 6851919 | Self-adhesive front panel. | |
| 6143502 | PG9 cable gland. | |

¹ CTX 300 CO₂ detector delivered before July 2015

Chapter 7 | Certification

The following page reproduces the EC declaration of conformity.



DECLARATION DE CONFORMITE CONSTRUCTEUR
Manufacturer Declaration of Conformity



La Société **Oldham S.A.S.**, 62000 Arras France, atteste que les
*The Company **Oldham S.A.S.**, 62000 Arras France, declares that the*

Détecteurs de gaz CTX 300
Gas Detectors CTX 300

sont conformes aux exigences des Directives Européennes suivantes :
comply with the requirements of the following European Directives :

La Directive Européenne CEM 2004/108/CE du 15/12/2004 : Compatibilité Electromagnétique
The European Directive EMC 2004/108/CEE of 15/12/2004: ELECTROMAGNETIC COMPATIBILITY

Normes harmonisées appliquées : **EN 50270:06** for type 1 CEM-Appareils de détection de gaz
Harmonised applied Standards *EMC-Apparatus for the detection of gases*

Arras, le 19/12/2013

Michel Spellenaecker

Global Director of Product Management



Oldham S.A.S.
ZI EST - CS 30419
62021 ARRAS Cedex - FRANCE
Tél : +33(0)3 21 60 30 50
www.oldham.com

CE_CTX 300 _ed 1



The company Oldham S.A.S., ZI Est, 62000 Arras France, declares that following materials intended for halogenated refrigerant fluid detection,

Gas detectors OLCT 10 & CTX 300

comply with the requirements of the European standard EN 14624 :

Performances of portable leak detectors or atmosphere controllers of halogenated refrigerant fluids.

Technical specifications

Equipment category : Non selective atmosphere controllers
 Measuring range : 0-2000 ppm R134a
 Minimum sensitivity threshold : 10 ppm R134a
 Maximum sensitivity threshold : 5000 ppm R134a during 90s without loss of sensitivity
 Minimum alarm threshold : 200 ppm R134a
 Minimum time to detect the lowest concentration : less than 25s after injection of 500 ppm R134a
 Recovery time : less than 160s after injection of 1000 ppm R134a during 8 minutes

Note 1 : For more information about installation, commissioning or safe practices please refer to the user manual of the manufacturer.

Note 2 : Local regulation may apply. For France, please refer to articles R.543-75 to R.543-123 in section 6 of the French Environmental Code (decree #2007-1467 dated from October 12, 2007 and decree #2011-396 dated from 2011, April 13).

Arras, 21/10/2013

Michel Spellenaecker




Oldham S.A.S.
 ZI EST - BP 417
 62021 ARRAS Cedex - FRANCE
 Tel : +33(0)3 21 00 20 20
www.oldhamgas.com



Global Director of Product Management

EN 14624_OLCT 10 _ed_b

Chapter 8 Technical specifications

| | |
|-----------------------|--|
| Enclosure. | Polycarbonate housing. |
| Function. | Detector-transmitter |
| Display | Highly visible backlight display unit (optional, gas dependent) |
| Indicator lights | In operation: green color (on CTX 300 : 3-wire) Failure / maintenance: yellow color |
| Link | 2 wires – CTX 300 without display unit 3 wires – CTX 300 with display unit |
| Cable entry | PG9 cable gland (outer diameter 6 to 11 mm) |
| Power supply | 15 to 32 V DC |
| Power consumption | CTX 300 without display unit: 27 mA CTX 300 with display unit: 110 mA Infrared or semiconductor versions: 100mA |
| Operating temperature | -40°C to + 50°C, 40°F to + 122°F sensor dependent |
| Sealing | IP 54, NEMA 3 & 3R |
| Weight | 520 g |
| Dimensions | 130 x 136 x 69 (l x h x d) in mm ; (5.12" x 5.35" x 2.72") |
| Certification |  CCSA – Class 4812 10 – Signal Appliances-Detectors CSAUS – Class 4812 86 - Signal Appliances-Miscellaneous |
| EMC | Type 1 according to EN 50270:06 |
| Impedance | 32 ohms max loop for CTX 300 with display unit and for solid states and CO ₂ sensor versions 128 ohms max loop for CTX 300 without display unit |

| Gas | Type of sensor | Range (ppm) | Operating temperature | Relative humidity uncondensed | Accuracy (at PA full scale) | Life span (in month) | T(50) (seconds) |
|------------------|----------------|-------------|-----------------------|-------------------------------|-----------------------------|----------------------|-----------------|
| O ₂ | EC | 30.0% | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 28 | 10 |
| | | 30.0% | -40°C to +50°C | 10% à 95% RH | +/-1.5% | 60 | 10 |
| | | 100% | +5°C to +40°C | 10% to 95% RH | +/-1.5% | 36 | <20 |
| CO | EC | 100 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 48 | 15 |
| | | 300 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 48 | 15 |
| | | 1000 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 48 | 15 |
| | | 1.00% | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 48 | <20 |
| | | 10.0% | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 48 | <20 |
| CO ₂ | IR | 1% | -30°C to +45°C | 5% to 95% RH | +/-2% | 60 | 70(T90) |
| | | 5% | -30°C to +45°C | 5% to 95% RH | +/-2% | 60 | 70(T90) |
| | | 10% | -30°C to +45°C | 5% to 95% RH | +/-2% | 60 | 70(T90) |
| | | 50% | -30°C, to +45°C | 5% to 95% RH | +/-2% | 60 | 70(T90) |
| H ₂ S | EC | 30.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| | | 100 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| | | 1000 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| NO | EC | 100 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| | | 300 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| | | 1000 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| NO ₂ | EC | 10.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 24 | 20 |
| | | 30.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 24 | 20 |
| SO ₂ | EC | 10.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| | | 30.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| | | 100 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 36 | 15 |
| Cl ₂ | EC | 10.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 24 | 50 |
| H ₂ | EC | 2000 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 24 | 50 |
| | | 2.0% | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 24 | 50 |
| HCl | EC | 30.0 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 18 | 50 |
| | | 100 | -20°C to +50°C | 10% to 95% RH | +/-1.5% | 18 | 50 |
| HCN | EC | 10.0 | -20°C to +50°C | 10% to 95% RH | +/-2% | 24 | 30 |
| | | 30.0 | -20°C to +50°C | 10% to 95% RH | +/-2% | 24 | 30 |
| NH ₃ | EC | 100 | -20°C to +40°C | 10% to 95% RH | +/-3% | 24 | <20 |
| | | 100 | -40°C to +40°C | 10% to 95% RH | +/-3% | 24 | <20 |
| | | 1000 | -20°C to +40°C | 10% to 95% RH | +/-3% | 24 | <20 |
| | | 5000 | -20°C to +40°C | 10% to 95% RH | +/-3% | 24 | <20 |
| ETO | EC | 30.0 | -20°C to +50°C | 10% to 95% RH | +/-3% | 36 | 50 |
| HF | EC | 10.0 | -10°C to +30°C | 10% to 95% RH | +/-3% | 12 | 50 |
| O ₃ | EC | 1.00 | -20°C to +50°C | 10% to 95% RH | +/-3% | 18 | 40 |

| Gas | Type of sensor | Range (ppm) | Operating temperature | Relative humidity uncondensed | Accuracy (at PA full scale) | Life span (in month) | T(50) (seconds) |
|--------------------|----------------|-------------|-----------------------|-------------------------------|------------------------------------|----------------------|-----------------|
| PH ₃ | EC | 1.00 | -20°C to +50°C | 10% to 95% RH | +/-3% | 12 | 40 |
| ASH ₃ | EC | 1.00 | -20°C to +50°C | 10% to 95% RH | +/-3% | 12 | 40 |
| ClO ₂ | EC | 3.00 | -20°C to +50°C | 10% to 95% RH | +/-2% | 24 | 50 |
| COCl ₂ | EC | 3.00 | -20°C to +40°C | 10% to 95% RH | +/-1.5% | 18 | 50 |
| Methylene chloride | SC | 500 | -20°C to +55°C | 10% to 95% RH | +/-15% relative to alarm threshold | 36 | 40 |
| Methyl chloride | SC | 500 | -20°C to +60°C | 10% to 95% RH | | 36 | 40 |
| Toluene | SC | 500 | -20°C to +50°C | 10% to 95% RH | | 36 | 20 |
| | | 2000 | -20°C to +50°C | 10% to 95% RH | | 36 | 20 |
| Trichloroethylene | SC | 500 | -20°C to +60°C | 10% to 95% RH | | 36 | 40 |
| Xylene | SC | 500 | -20°C to +50°C | 10% to 95% RH | | 36 | 20 |
| | | 2000 | -20°C to +50°C | 10% to 95% RH | | 36 | 20 |
| Ethanol | SC | 500 | -20°C to +50°C | 10% to 95% RH | | 36 | 20 |
| | | 5000 | -20°C to +60°C | 10% to 95% RH | | 36 | 20 |
| R12 | SC | 10000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R22 | SC | 2000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R123 | SC | 2000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R134a | SC | 2000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R11 | SC | 10000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R23 | SC | 10000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R143a | SC | 2000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R404a | SC | 2000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R507 | SC | 2000 | -20°C to +55°C | 10% to 95% RH | | 36 | 30 |
| R410a | SC | 1000 | -20°C to +55°C | 10% to 95% RH | | 36 | 20 |
| R32 | SC | 1000 | -20°C to +55°C | 10% to 95% RH | | 36 | 20 |

EC : Electrochemical

IR : Infrared

SC : Semiconductor

Chapter 9 | Annex

Indications for calibrating the CTX 300 SC

This information relates to the CTX 300 semiconductor.

| P/N | Gas types | Measurement range | After sale service standard gas | Test gas |
|---------|---|-------------------|---|--|
| 6313545 | Methane CH ₄ | 100% LEL | 20 % LEL 1 % CH ₄ | |
| | Hydrogen H ₂ | 100% LEL | 20 % LEL 0.8 % H ₂ | |
| | Butane C ₄ H ₁₀ | 100% LEL | 20 % LIE LEL 0.37 % C ₄ H ₁₀ | |
| | Propane C ₃ H ₈ | 100% LEL | 20 % LEL 0.4 % C ₃ H ₈ | |
| | Methyl Chloride CH ₃ Cl | 500 ppm | 50 ppm CH ₃ Cl | 2000 ppm H ₂ = 190 ppm ± 25ppm |
| | Methylene chloride CH ₂ Cl ₂ | 500 ppm | 100 ppm CH ₂ Cl ₂ | 100 ppm CO = 80ppm ± 15 ppm |
| 6313546 | Trichloroethylene C ₂ HCl ₃ | 500 ppm | 75 ppm Trichloroethylene | 300 ppm CO = 120 ppm ± 35ppm |
| | Toluene C ₆ H ₅ CH ₃ | 2 000 ppm | 100 ppm Toluene | 300 ppm CO = 330ppm ± 50ppm |
| | Xylene C ₆ H ₄ (CH ₃) ₂ | 2 000 ppm | 100 ppm Xylene | 300 ppm CO = 330ppm ± 50ppm |
| | Ethanol C ₂ H ₅ OH | 5 000 ppm | 1000 ppm Ethanol | 1000ppm H ₂ = 880ppm ± 150ppm |
| 6313547 | Freon R12 | 1 % volume | 1000 ppm R12 | 0.5%CH4=overscale |
| | Freon R22 | 2000 ppm | 1000 ppm R22 | 0.5% CH4 = 750ppm ± 200ppm |
| 6313544 | Freon R134A | 2000 ppm | 1000 ppm R134A | 0.5% CH4 = 2000ppm ± 500ppm |
| | Freon R11 | 1% volume | 1000 ppm R134A = 150 ppm | 0.5% CH4=overscale |
| | Freon R23 | 1% volume | 1000 ppm R22 = 4500ppm | 0.5% CH4 = 2800ppm ±800ppm |

CTX 300 overview




Figure 41: CTX 300 with sensor pack and display – overview.




Figure 42: CTX 300 – overview.




Figure 44: CTX 300 infrared – 1% volume CO₂ – overview.





Figure 45: CTX 300 infrared – 5% volume CO₂ – overview.






Figure 47: CTX 300 infrared – 50% volume CO₂ – overview.



EUROPEAN PLANT AND OFFICES

Z.I. Est – rue Orfila CS 20417 – 62027 Arras Cedex FRANCE

Tél: +33 (0)3 21 60 80 80 – Fax: +33 (0)3 21 60 80 00

Website: <http://www.oldhamgas.com>

AMERICAS

Tel: +1 713-559-9280

Fax: +1 281-292-2860

americas@oldhamgas.com

ASIA PACIFIC

Tel: +86-21-3127-6373

Fax: +86-21-3127-6365

sales@oldhamgas.com

EUROPE

Tel: +33-321-608-080

Fax: +33-321-608-000

info@oldhamgas.com